

4G vehicle monitoring terminal equipment

Instructions

1.Product overview

GT10 is a 4G monitoring terminal inside and outside the car, with high-definition car DVR camera, one-key alarm, positioning, WIFI, 4G communication, voice control recognition, and external expansion capacity storage multi-function machine, in line with JT/1078 "Road Transport Vehicle Satellite" Positioning System Video Communication Protocol" and the technical requirements of JT/808 "Technical Specification for Road Transport Vehicle Satellite Positioning System GPS Compatible Vehicle Terminal Communication Protocol".

2.Appearance of the product



3. Equipment power supply requirements .

The equipment is powered by 12V. If you need to install a large truck or a 24V voltage vehicle, you need to connect an external 24V-12V step-down box.

4. Definition of indicator lights

1. Blue light network indicator light, flashes when the network is abnormal;
2. green GPS indicator light, flashes when GPS positioning is abnormal, all functions of the machine are normal and is always on;
3. red light recording indicator light, flashes when video recording is abnormal;

5. Button Definition

1. Short press - broadcast WIFI hotspot, machine working status; long press - restart the device;
2. long press until the red light and green light are on at the same time after shutdown - restore factory settings.

6. Linking APP(clouddvr)

1. Mobile phone scan code download(clouddvr)



1. Open the mobile phone WIFI and search for GT10;
2. the password is: 12345678
3. The mobile phone is bound to the device (it must be turned on next to the device and the network is in normal state) Open the mobile phone to search for the GT10 hotspot to connect to the device WIFI, then open the video cloud car APP, click the device in the upper right corner, and the available devices will pop up. Click the available devices in English and numbers , a binding request will be sent, click OK and then press the circle button on the device, and the device will send an agreement to bind.




1. Clouddvr




2. Way of inserting sim card





3. 4G mean sim card works





4. When press location




5. When press DVR files





6. When press setting



7. When push SOS button




8. When press set




7. Linking APP(CMSV6)


1.Login(I shall give you login info) 2.After login




3. Press the car model




4. When press map



5. When press video



6. When press message




8. Linking PC (CMSV6)


http://faq.cmsv8.com/web/#/3?page_id=425




1.dashboard




2.Map



3.video



4.safety



5.track

System View Settings 道路安全监督平台 Dashboard Map Video Safety Mon **Track** Record Manage Other Cloud Screen

Search The Terminal 053810857304053810857304

Address

2022年3月

Start Time: 2022-03-11 00:00:00
End Time: 2022-03-11 23:59:59

Other: Spacing: 0 KM, Parking: 180 Sec, Message: 0, Mode: Normal, Show: Draw Line After Search, Show Track Points, Autoplay, Display A Device Position

Track	Number	Date / Receive Time	Position	Downlink	Speed	Drive Recorder Speed	Supplement	Message	Driver Info	Status	Alarm
Data Record	8	05381085730	2022-03-11 13:36:36 / 20	广东省深圳市福田区5940深圳	0 km/h	0 km/h	No	ACC ON, GPS Disabled, Network signal poor		ACC ON, GPS Disabled, Network signal poor	
	9	05381085730	2022-03-11 13:36:46 / 20	广东省深圳市福田区5940深圳	0 km/h	0 km/h	No	ACC ON, GPS Disabled, Network signal poor		ACC ON, GPS Disabled, Network signal poor	
	10	05381085730	2022-03-11 13:36:56 / 20	广东省深圳市福田区5940深圳	0 km/h	0 km/h	No	ACC ON, GPS Disabled, Network signal poor		ACC ON, GPS Disabled, Network signal poor	
	11	05381085730	2022-03-11 13:37:06 / 20	广东省深圳市福田区5940深圳	0 km/h	0 km/h	No	ACC ON, GPS Disabled, Network signal poor		ACC ON, GPS Disabled, Network signal poor	
	12	05381085730	2022-03-11 13:37:16 / 20	广东省深圳市福田区5940深圳	0 km/h	0 km/h	No	ACC ON, GPS Disabled, Network signal poor		ACC ON, GPS Disabled, Network signal poor	
	13	05381085730	2022-03-11 13:37:26 / 20	广东省深圳市福田区5940深圳	0 km/h	0 km/h	No	ACC ON, GPS Disabled, Network signal poor		ACC ON, GPS Disabled, Network signal poor	
	14	05381085730	2022-03-11 13:37:36 / 20	广东省深圳市福田区5940深圳	0 km/h	0 km/h	No	ACC ON, GPS Disabled, Network signal poor		ACC ON, GPS Disabled, Network signal poor	
	15	05381085730	2022-03-11 13:37:46 / 20	广东省深圳市福田区5940深圳	0 km/h	0 km/h	No	ACC ON, GPS Disabled, Network signal poor		ACC ON, GPS Disabled, Network signal poor	
	16	05381085730	2022-03-11 13:37:56 / 20	广东省深圳市福田区5940深圳	0 km/h	0 km/h	No	ACC ON, GPS Disabled, Network signal poor		ACC ON, GPS Disabled, Network signal poor	
	17	05381085730	2022-03-11 13:38:07 / 20	广东省深圳市福田区5940深圳	0 km/h	0 km/h	No	ACC ON, GPS Disabled, Network signal poor		ACC ON, GPS Disabled, Network signal poor	
	18	05381085730	2022-03-11 13:38:17 / 20	广东省深圳市福田区5940深圳	0 km/h	0 km/h	No	ACC ON, GPS Disabled, Network signal poor		ACC ON, GPS Disabled, Network signal poor	

6. record

System View Settings 道路安全监督平台 Dashboard Map Video Safety Mon **Record** Manage Other Cloud Screen

Select Device: 053810857304

Search Time: 2022-03-11, Start Time: 00:00:00, End Time: 23:59:59

Video Files Location: (No Type), Vehicle Device: (None), Media type: Audio and video, Stream Type: Main Stream, Store Type: Main, Alarm Type: (None)

06:48:07 1x 06:36:12 11 KB/s / 427 KB

Date: CH1, File: CH2, Download: CH3, FTP Upload: CH4

Running: 005.12026 CPU: 89.0% RAM: 100.00%

7.manage

The screenshot displays the 'Active Safety Handle' management interface within the 'Active Security Cloud Platform'. The top navigation bar includes 'System', 'View', 'Settings', and '道路安全監管平台'. The main menu features 'Dashboard', 'Map', 'Video', 'Safety Hiss', 'Track', 'Record', 'Manage', and 'Other'. The left sidebar lists various functions such as 'Alarm Handling', 'Active Safety Handle', 'Active Safety Alarm Appeal', 'Platform active security alarm processing', 'Active Safety Query', 'Alarm Handle Analysis', 'Alarm false positive query', 'Alarm false positive analysis', 'Ticket Handling', 'Ticket File', 'Driver Identification RPT', 'Evidence Center', 'Alarm Analysis', 'Active Security Risk Portrait', 'Safety RPT', 'Customize', 'OperationReport', and 'Intelligent risk control operation report'. The main content area is titled 'Active Safety Handle' and includes search filters for 'Start Time' (2022-03-11 00:00:00) and 'End Time' (2022-03-11 23:59:59). Below the filters is a table with columns: Index, Operate, Attachment, Plate No., Driver, Company, Plate Color, Vehicle Type, Alarm Type, Alarm Leve, Alarm Sour, Start Time, End Time, and Alarm Duration. The table is currently empty. At the bottom, there is a pagination control showing 'Per Data 15', 'Page Total 1 Page', and navigation arrows.